

QCK09 Baclyser Inline Screw-On Push Connect Kit

The **QCK09 InLine Screw-On Quick Connect Kit** is recommended as an option for the installation and maintenance of Baclyser Inline filters in ice machine or inline applications. The InLine Screw-On Quick Connect Kit can simplify the installation and maintenance of the Baclyser Inline filters on facility equipment and provide a standardized interface.

Screw on Push Connections for the Baclyser IL3, IL5 & IL10

With one compression adapter, two lengths (approx. 18" each) of 3/8" tubing, and various push connect adapters, installation of Baclyser filters can be finished in minutes. To install, attach the compression adapter directly to the shut off valve tee. Screw on the female thread x push connect adapters to the filter and the remaining stem elbow and flare fitting in combination to the ice machine water supply (connections may vary). The collet locking system holds the tube firmly in place without deforming it or restricting water flow. When it is time to change out the filter, depressurize the system and pull the tubing out of the fittings and discard.



	Part	Qty.	Description
	Compression Adapter	1	3/8" OD (Tube) x 9/16"-24 UNEF (3/8" Compression) female connector
	Tubing*	3	3/8" LDPE Tubing, Blue (approx. 3' length per kit; sold per foot)
	Female Adapter	2	3/8" OD (Tube) x 1/2" BSPP Female Adapter
	Flare Adapter	1	3/8" OD (Tube) x 3/8" FFL Female Flare Adapter
	Stem Elbow	1	3/8" OD (Tube) x 3/8" Stem Elbow
	Bracket Screw	2	#10-3/4" Stainless Steel Screw
	Mounting Bracket	2	2.5" White Filter Mounting Bracket Clip (for IL10)
			<i>Recommended Installation Items Sold Separately</i>
	Bracket Insert	1	2.2" Reducer Insert Clip (for use with IL5 filters)

Tubing delivered full length (approx. 3' per kit) times total number of kits ordered. Connector parts are available through AquaMedix or by order through limited vendors. Threaded filter connections may additionally be wrapped with thread seal tape (PTFE tape/plumber's tape) to provide thread lubrication, although thread tape is not required to form a seal for parts with gaskets. **Do not use pipe thread compound on IL filters. Use only flat or cone IPS/BPSS thread connectors with gaskets on filters.*

Please contact info@aquamedix.net for further support if you experience issues during installation.